




APL 400 Series

Local language versions are available for download on www.vivostat.com/qrcs

PART 1 – PREPARE DISPOSABLE APPLICATOR DEVICE AND APPLICATOR UNIT


Turn ON Applicator Unit on the back and connect foot switch (if using this)




1. Place 21g needle just inside pH 10 vial, draw fluid into 1 ml syringe



2. Transfer disposable applicator + pH-paper to sterile area




3. Transfer syringe holder out of sterile area




4. Insert pH 10 and Vivostat® Fibrin syringes into syringe holder



5. When indicated in display, open shield



6. Insert and position syringe holder



7. Press syringe holder into cavity using two fingers




8. Close shield

CAUTION:

To avoid air bubbles impacting mixture negatively do NOT push needle to the end of pH 10 vial in Step 1


PART 2 – LOAD SYRINGES, PRIME AND INITIATE APPLICATION




1. Take cap off Spraypen




2. Press button to start loading syringes



3. Press Spraypen button or foot switch once to prime




4. Point to lower corner of pH-paper while auto-priming



5. Auto-priming stops automatically and ml + spray mode is displayed




6. Verify correct mixture on pH-paper (from liquid to viscous in 10-30 sec.)




7. Ready for application


ADDITIONAL APPLICATION TIPS




Use circular movements in a 2-6 cm spray distance




Do NOT poke tissue and bend Spraypen tip



Avoid touching the applied substance immediately after application



If pausing application +5 minutes, put cap on Spraypen



Remove cap and wipe tip of Spraypen prior to reapplying